

# Instructions for Linbar<sup>®</sup> and Multibar<sup>®</sup> Part # 604-1, 13604

Fits Yamaha V-Star Classic & Custom  
1100 cc 1998-up

**LINDBY  
CUSTOM, INC.**

[www.lindbycustom.com](http://www.lindbycustom.com)

320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove left and right floorboards and install flat stock brackets between frame and bracket for the floorboards. Do not tighten bolts yet.
2. Remove two 6mm bolts placed under lower triple three and install the highway bar reusing the two 6mm bolts. Do not tighten yet.
3. Connect the lower mounts of the Linbar / Multibar to the previously installed flat stock brackets.
4. Lift up highway bar and make sure that the Linbar / Multibar is level and tighten down all the bolts to the manufacturer's specifications.
5. Turn handlebars to the left and right to make sure that the brake line is clear between fork and highway bar, adjust guides if necessary.

